

New weather bar fixing method

1. Calculate centre of door leaf. Width divided by 2.
2. Screw support screws into exterior door leaf as shown x 3 outer screws to be 100mm inboard of door leaf. Ensure all screws in line with each other.
3. Recommended screw height 35mm low threshold type frame. 50mm full frame.
4. Locate weather bar onto screw. Ensure located as shown in fig 4
5. Tap / slide across locating all 3 screws onto weather bar. Attach end caps.
6. Once fixed run a bead of silicone across the entire underside of the fitted weather bar.

